








MODEL	A	B	C	D	E	G	H	J	K	L	M	P
HVF-42-P	45" [1067]	18" [457]	37 3/4" [959]	37 3/4" [959]	5" [127]	5" [127]	48 5/8" [1299]	28 1/8" [714]	47" [1194]	18" [457]	1/2" [13]	19 1/8" [485]
HVF-60-P	62 1/2" [1588]	18" [457]	37 3/4" [959]	49 1/8" [1248]	5" [127]	5" [127]	68 1/4" [1734]	28 1/8" [714]	65 1/8" [1654]	18" [457]	1/2" [13]	19 1/8" [485]
HVF-72-P	74 1/2" [1892]	18" [457]	37 3/4" [959]	59 1/4" [1505]	5" [127]	5" [127]	77 3/4" [1975]	28 1/8" [714]	77" [1956]	18" [457]	1/2" [13]	19 1/8" [485]

This information is for reference only. Please consult the Installation Manual for all details prior to making any design decisions.
Conversions from millimeters are rounded to the nearest fraction.

