



LOG INSTRUCTIONS



IMPORTANT

WARNING: DC SUPPLY 12V

- IMPORTANT: Each log must be wired in the correct order and direction or a failure will occur. Disconnect the fire from the mains power supply until installation is complete.



IMPORTANT

All E-FX Lite Fires come with the log set pre installed, but replacement part numbers are available for any parts needed.

CONTENTS

What's in the box.....	4
E-FX Log Instructions.....	6
E-FX Log Layouts.....	12
E-FX - SL Log Layouts	13
Spares & Repairs Codes	14

BOX CONTENTS



E-GLO LOGS



BLACK GLASS



CLEAR GLASS



GREY CHIPS



TOUCH-UP PAINT



VERMICULITE

E-FX LOG INSTRUCTIONS

IMPORTANT

Each log must be wired in the correct order and direction or a failure will occur. Refer to the instructions before undertaking installation of the logs. Disconnect the fire from the mains power supply until installation is complete.

01 - PLACE THE LOGS

Starting at the right hand side, place the logs in the positions shown printed on the fuel bed. The logs have numbers on that tell you where to put them. See Page 12 for the layout for your fire.



02 - CONNECT THE LOGS

Starting at the right hand side again, plug Log 1 into the connector marked A on the fuel bed.

IMPORTANT

Make sure that the connectors are fitted securely and fully engaged. Poor connections lead to faults.

E-FX LOG INSTRUCTIONS

03 - CONNECT THE LOGS

Connect the logs together using the wires. You can only plug them in one way. Work your way from right to left, making sure all connections are tight and secure.



E-FX LOG INSTRUCTIONS

04 - CONNECT THE FUEL BED

Connect the far left log to connector B. This completes the log wiring.



E-FX LOG INSTRUCTIONS

05 - HIDE THE CONNECTORS

Now everything is connected, make sure all the wires are hidden behind or underneath the logs, making sure you can not see them.



06 - ADD THE LIGHT EMBERS

Printed on the fuel bed are outlines showing where the different types of aggregate go. Starting with the clear glass, place the crushed glass onto the fuel bed.



E-FX LOG INSTRUCTIONS

07 - ADD THE DARK EMBERS

To make your fire look even more realistic, place the black glass on top of the clear glass. Use about 25% black glass to 75% clear glass so you still get lots of light from your fuel bed.



E-FX LOG INSTRUCTIONS

08 - ADD THE ASHES

Using the bag called vermiculite, sprinkle the ashes over the fuel bed where there is empty space. Make sure any free space is covered by the ashes.



E-FX LOG INSTRUCTIONS

09 - THE FINISHING TOUCH

Finally, using the bag labelled grey chips, scatter the chips across the fuel bed, so that it creates the effect of burnt wood, putting the final touch on your fuel bed.



E-FX LOG LAYOUTS



E-FX 450



E-FX 1000



E-FX 1300



E-FX 1500



E-FX 1800

E-FX SL LOG LAYOUTS



E-FX SL 600



E-FX SL 750



E-FX SL 1000

PART CODES

PART NAME	PART CODE
E-FX Log 1	FE191
E-FX Log 2	FE192
E-FX Log 3	FE193
E-FX Log 4	FE194
E-FX Log 5	FE195
E-FX Log 6	FE196
E-FX Log 7	FE197
E-FX Log 8	FE198
E-FX Log 9	FE199
E-FX Log 10	FE200
Touch Up paint	FE215
Clear Glass	FE216
Black Glass	FE218
Vermiculite	FE213
Grey Chips	FE214
E-FX SL - Log 1	FE201
E-FX SL - Log 2	FE202
E-FX SL - Log 3	FE203
E-FX SL - Log 4	FE204
E-FX SL - Log 5	FE205
E-FX SL - Log 6	FE206
E-FX - Log 7	FE207

NOTES



www.flameritefires.com/efx

Flamerite Fires Ltd, Greenhough Road, Lichfield, Staffordshire WS13 7AU

Tel: +441543 251122 | **Fax:** +441543 251133 | **Email:** info@flameritefires.com

These products are only suitable for well insulated spaces or occasional use.

Manufactured in the United Kingdom. All products are protected by patents, registered design and intellectual property rights. Flamerite Fires Ltd. will protect these rights.

All specifications are correct at the time of publishing but are subject to change.



ELECTRIC FIRES MADE IN EUROPE